
















BCP/B390


Assembly Instruction

Thank you for purchasing our products.


Please read the assembly instructions carefully before assembling.

| | |
|---|--|
| A*5  | B*1  |
| C*1  | D*1  |
| E*1  | F*1  |
| G*1  | H*1(L&R)  |
| I*1  | J*1  |
| K*1(L&R)  | L*14  M8*20mm |
| M*2  M5*10mm | N*4  |
| O*1  | |


①




②




③



④



⑤



⑥

