



Showerhead Care

EC9+ Washroom

Single product procedure for
descaling and disinfecting
showerheads

Cleaning and Descaling



Make up a solution of **EC9+**
2 x 10 ml caps EC9+ to 5 L warm water.

Dismantle the showerhead and hose and
soak in the solution for 30 minutes.

Agitation with a nylon scrubbing brush
may be necessary to remove heavy soil
and limescale.

Discard used solution safely and flush the
showerhead and hose with clean water.

Disinfecting



To kill a range of bacteria including
Legionella pneumophila*:

Make up a solution of **EC9+**
at a dilution rate of 1:60 warm water.

Add showerhead and hose to the solution
and soak for a minimum of 5 minutes.

Discard used solution safely and flush the
showerhead and hose with clean water.

Re-assemble showerhead and hose ready
for use.

This procedure should be carried out every
3 months.

* EC9+ is suitable for disinfecting showerheads only and should not be
used in water systems for the control of Legionella.